

AD-A063 091

ADMIRALTY UNDERWATER WEAPONS ESTABLISHMENT PORTLAND --ETC F/G 11/6  
MICROSTRUCTURAL CHARACTERISATION OF CAST NICKEL ALUMINIUM BRONZ--ETC(U)  
JUN 78 E A CULPAN, G ROSE

UNCLASSIFIED


AUWE-TN-580/78

DRIC-BR-65483

NL

1 OF 1  
AD  
A063091





MICROCOPY RESOLUTION TEST CHART  
NATIONAL BUREAU OF STANDARDS-1963-A

ACC. No. 46194

AD A063091

A.U.W.E. Tech. Note 580/78

DDC FILE COPY

U.D.C. No.  
669. 35. 71:  
669. 245. 71:  
539. 2

UNLIMITED

① LEVEL II

A.U.W.E. Tech. Note 580/78

JUN 1978

11

AUWE-TN-580/78

14

AUWE-ACC-46194

Copy No. 15

6

② 33p.

MICROSTRUCTURAL CHARACTERISATION  
OF CAST NICKEL ALUMINIUM BRONZE.

⑨ Technical notes

BY

10

E.A. CULPAN  
G. ROSE

⑮ DRIC  
⑰ BR-65483

DDC  
RECEIVED  
JAN 11 1979  
B

DISTRIBUTION STATEMENT A

Approved for public release  
Distribution Unlimited

ADMIRALTY UNDERWATER WEAPONS ESTABLISHMENT

PORTLAND

78 12 27 040

UNLIMITED

004 550

UNCLASSIFIED/ UNLIMITED

lpg

The views expressed herein do not necessarily represent the considered opinion of the issuing establishment and must not be taken to define Ministry of Defence (Naval) or Departmental policy.

## AMENDMENTS

[illegible]



DETACHABLE ABSTRACT CARDS

THE ABSTRACT CARDS DETACHED  
FROM THIS DOCUMENT ARE  
LOCATED AS FOLLOWS:-

1 \_\_\_\_\_ 2 \_\_\_\_\_

3 \_\_\_\_\_ 4 \_\_\_\_\_

ACC. No. 46194

U.D.C. No.  
669.35.71:  
669.245.71:  
539.2

A.U.W.E. Tech. Note 580/78  
JUNE 1978

# MICROSTRUCTURAL CHARACTERISATION OF CAST NICKEL ALUMINIUM BRONZE

BY

E.A. CULPAN

G. ROSE

A.U.W.E. Tech. Note 580/78

ADMIRALTY UNDERWATER WEAPONS ESTABLISHMENT  
PORTLAND

(Duplicate Front Cover for filming purposes)

UNCLASSIFIED/ UNLIMITED

UDC No 669.35.71:  
669.245.71:  
539.2

AWE Technical Note No 580/78  
July 1978

MICROSTRUCTURAL CHARACTERISATION OF CAST NICKEL ALUMINIUM BRONZE

by

E A Culpan  
G Rose

ACCESSION for	
MTS	White Section <input checked="" type="checkbox"/>
DOC	Buff Section <input type="checkbox"/>
UNANNOUNCED	<input type="checkbox"/>
JUSTIFICATION	
BY	
DISTRIBUTION/AVAILABILITY CODES	
Dist. AVAIL and/or SPECIAL	
A	

CONTENTS

	<u>Page No.</u>
Duplicate Front Cover ... ..	(i)
	(ii) Blank
Title Page ... ..	(iii)
Contents ... ..	(iv)-(v)
	(vi) Blank
Distribution (Detachable) ... ..	(vii)
	(viii) Blank
Precis ... ..	1
Conclusions ... ..	1
Recommendations ... ..	1
	2 Blank
Introduction ... ..	3
Cast Alloy Microstructures ... ..	3-4
Development of Microstructure ... ..	4-6
Heat Treatment of Nickel Aluminium Bronze ... ..	6
Chemical Analysis of Constituent Phases ... ..	7
Analysis Techniques ... ..	7-8
Results ... ..	9-10
References ... ..	10
Table 1. Analyses of phases ... ..	4
Table 2. Phase transformations ... ..	5
Table 3. Calibration factors (k) for JEOL 100B/STEM at 100 KV ... ..	8
Table 4. Chemical analysis of phases present in cast nickel aluminium bronze ... ..	11
Table 5. Chemical analysis of the fine precipitates within the $\alpha$ phase of heat treated nickel aluminium bronze ... ..	12
Document Control Sheet ... ..	13
	14 Blank
Abstract Cards (Detachable) ... ..	15



ILLUSTRATIONSFigure

- 1a Vertical section of the Cu-Al-Ni-Fe system at 5% Ni, 5% Fe.
- 1b Binary Cu-Al system.
- 2 Schematic representation of phase breakdown.
- 3 Microstructure of sand cast nickel aluminium bronze showing constituent phases.
- 4 Alloy quenched from 1000°C showing as solidified  $\beta$  grain size.
- 5 Alloy slowly cooled from 1000°C to 900°C and quenched, showing nucleation of  $\alpha$  phase.
- 6 Alloy slowly cooled from 1000°C to 825°C and quenched, showing nucleation of globular  $\kappa_I$  with  $\alpha$  and  $\beta$  phases.
- 7 Alloy slowly cooled from 1000°C to 800°C and quenched, showing formation of  $\kappa_{II}$  and  $\kappa_{III}$  at the  $\alpha/\beta$  interface.
- 8 Alloy slowly cooled from 1000°C to 725°C and quenched, showing fine  $\kappa_{IV}$  precipitation within the  $\alpha$  grains.
- 9 Alloy slowly cooled from 1000°C to 675°C and quenched, showing typical as-cast structure.
- 10 Alloy slowly cooled from 1000°C to 775°C and quenched, showing lamellar  $\kappa_{III}$  and globular  $\kappa_{II}$  phase forming together.
- 11 Rosette  $\kappa_I$  surrounded by lamellar  $\kappa_{III}$  phase.
- 12 Lamellar  $\kappa_{III}$  phase.
- 13 Alloy heat treated at 675°C for 6 hours, air cooled.
- 14 Alloy heat treated at 675°C for 2 hours, showing fine lath and globular precipitates.
- 15 Extraction replica of specimen shown in figure 14.
- 16 Alloy heat treated at 740°C for 3 hours.
- 17 Alloy heat treated at 790°C for 3 hours.
- 18 Alloy heat treated at 840°C for 3 hours.
- 19 Alloy heat treated at 675°C for 6 hours showing lath and globular precipitates.
- 20 Alloy heat treated at 675°C for 16 hours.
- 21 Alloy heat treated at 860°C for 72 hours.
- 22 Variation of  $\beta$  composition with respect to temperature.



## MICROSTRUCTURAL CHARACTERISATION OF CAST NICKEL ALUMINIUM BRONZE

### PRÉCIS

1. The morphology and chemical analysis of the complex phases present in cast nickel aluminium bronze of nominal composition 10% aluminium, 5% nickel and 5% iron, have been investigated using optical microscopy, scanning electron microscopy and scanning transmission electron microscopy, coupled to an energy dispersive analysis system. The development of the structure of nickel aluminium bronze from liquid metal to the room temperature structure has been followed and also the modifications to the structure produced by heat treatment.

### CONCLUSIONS

2. Optical and electron microscopy techniques have been successful in identifying and analysing the microstructural phases in cast nickel aluminium bronze, namely  $\alpha$ ,  $\beta$  and four  $\kappa$  phases.

3. The microstructural changes that occur during heat treatment lead to the precipitation of a further  $\kappa$  phase which differs in morphology and chemical composition to those present in as-cast structures.

### RECOMMENDATIONS

4. As the morphology and chemical composition of the phases in an alloy markedly affect its strength and corrosion behaviour, it is suggested that the above conclusions can be used to explain the varied properties of cast nickel aluminium bronze.

## INTRODUCTION

5. Nickel aluminium bronze cast alloy to BS 1400 AB2 is being used increasingly where high strength, high impact properties and good corrosion resistance are required. This alloy, of nominal composition 9.5% aluminium, 5% nickel, 5% iron and copper remainder has replaced the binary aluminium bronze in many applications. Under equilibrium conditions binary alloys, containing up to 9.4% aluminium, form a single phase  $\alpha$  solid solution at room temperature, with the strength being directly proportional to the aluminium content. Further addition of aluminium normally results in an  $\alpha + \beta$  structure in metal cooled at moderate rates, but decomposition of the  $\beta$  phase will occur during slow cooling or annealing below 565°C to form an  $\alpha + \gamma_2$  eutectoid. The presence of this eutectoid decreases both mechanical properties and corrosion performance, therefore steps have to be taken to eliminate the  $\gamma_2$  phase. One possibility is to heat treat the alloy between 600-800°C followed by a rapid air cool or quench which suppresses the  $\beta$  transformation but unless the cooling rate is sufficiently rapid the  $\gamma_2$  phase may still be formed. A further method is to add alloying elements which retard the formation of  $\gamma_2$  while maintaining the high strength properties that characterise aluminium bronze. The principal alloying elements used for this purpose are iron, nickel and manganese. Both nickel and iron combine with aluminium to form a complex phase, designated  $\kappa$ , which effectively increases the amount of aluminium which may be present in an alloy before  $\gamma_2$  phase is encountered. Approximately 1% manganese is usually present in these alloys to aid castability, and to retard the  $\beta$  transformation, and is considered to be equivalent to 0.15% aluminium on the phase diagram.

6. Because of the complex nature and small volume fraction of many phases present in nickel aluminium bronze, and the non-equilibrium cooling conditions usually encountered, identification and analysis of the phases and the mechanisms by which they are produced have proved difficult to determine. This paper describes an investigation using optical microscopy, scanning electron microscopy (SEM) and scanning transmission electron microscopy (STEM) coupled to an energy dispersive analysis system to characterise the phases present in this alloy system, and to follow the modifications to the structure produced by heat treatment. The amount and distribution of the phases in nickel aluminium bronze and their chemical composition has a significant effect on the properties of this material. The influence of microstructure on fracture behaviour<sup>(1)</sup> and on corrosion properties<sup>(2)</sup> are the subject of further publications.

## CAST ALLOY MICROSTRUCTURES

7. The constitution of the copper-aluminium alloys containing 5% nickel, 5% iron from the work of Cook, Fentiman and Davis<sup>(3)</sup>, is shown in Fig 1, together with the binary copper-aluminium diagram for comparison. According to earlier workers<sup>(4,5,6)</sup> the alloys complete solidification as a single phase  $\beta$  structure. On further cooling the  $\alpha$  phase grows at the  $\beta$  grain boundaries and along crystallographic planes to form a Widmanstätten structure. The nickel-iron-aluminium  $\kappa$  is then precipitated from the  $\beta$  as rounded or dendritic "rosettes" rich in iron, whereas at lower temperatures a lamellar form of  $\kappa$  is produced together with further deposition of  $\alpha$  on existing  $\alpha$  areas. This continues until all the  $\beta$  has transformed to  $\alpha$  and  $\kappa$  although small areas of retained  $\beta$  can be found in most as-cast structures. Finally there is a precipitation of a fine  $\kappa$  phase within the  $\alpha$  boundaries. This is summarised schematically in Fig 2.

8. Work by Weill-Couly and Arnaud<sup>(7)</sup> has identified various forms of the  $\kappa$  phase that are evident in cast nickel aluminium bronze, as shown in Fig 3. Using probe microanalysis they obtained an indication of the chemical composition of some of the phases. These were identified as follows:

$\kappa_I$  a rosette form of composition 6% Al, 8% Ni, 69% Fe, 13% Cu.

$\kappa_{II}$  and  $\kappa_{III}$  a globular or lamellar form of composition 18-20% Al, 23-24% Ni, 26-43% Fe, 13-20% Cu.

$\kappa_{IV}$  a fine precipitate within the  $\alpha$  grains, thought to be iron rich.

9. More recently Duma<sup>(8)</sup> investigated the structure and analysis of the  $\kappa$  phases, and identified the  $\kappa$  phases according to their morphologies. The analyses of the respective phases are shown in Table 1, together with the identification adopted by Weill-Couly and Arnaud.

Table 1

Phase	Composition Wt %			
	Cu	Al	Ni	Fe
Large globular phase ( $\kappa_I$ )	9	14	6.5	64
Lamellar two phase eutectoid ( $\kappa_{III} + \alpha$ )	82	9	3	3
Fine two phase intermixture ( $\kappa_{IV} + \alpha$ )	83	9	3	4
$\alpha$ matrix	87	6.5	7.5	3

Duma<sup>(8)</sup> did not isolate the  $\kappa_{III}$  and  $\kappa_{IV}$  during analysis and the results quoted include the surrounding  $\alpha$  matrix. In fact the analyses for  $\kappa_{III} + \alpha$  and  $\kappa_{IV} + \alpha$  are not very different from that of the  $\alpha$  matrix, indicating a low volume fraction of precipitate within the electron beam.

#### DEVELOPMENT OF MICROSTRUCTURE

10. Specimens used in this investigation were held at 1000°C for 1 hour and subsequently cooled to successively lower temperatures at 25°C intervals, at a rate of 8°C per minute, to simulate cooling of 25 mm castings, before quenching in cold water. Under these conditions the phase transformations occurred as shown in Table 2.



Table 2

Phase Transformation	Equilibrium Transformation Temperature °C	"25 mm Casting" Transformation Temperature °C
$\beta \rightarrow \alpha + \beta$	1010	925
$\beta \rightarrow \alpha + \kappa_I$	900-920	820-830
$\beta \rightarrow \alpha + \kappa_{II} + \kappa_{III}$	840-870	775-750
$\alpha \rightarrow \alpha + \kappa_{IV}$	-	700-675

11. Although non equilibrium cooling depresses the phase transformation temperatures it is interesting to note that the room temperature volume fractions of the various phases approach those predicted from the equilibrium diagram (Fig 1).

12. Figs 4 to 9 indicate the phase changes of nickel aluminium bronze at various temperatures. At 1000°C (Fig 4) the alloy is wholly  $\beta$  phase however on cooling to 900°C (Fig 5) areas of light etching  $\alpha$  are formed. Fig 6 indicates that the initial grey etching rosette  $\kappa$  phase precipitates randomly in the  $\alpha$  and  $\beta$  phases although traditionally thought to be formed only from the  $\beta$ . The break-down of the  $\beta$  phase is seen to take place at the  $\alpha/\beta$  boundaries - the lamellar phase grows at right angles to this  $\alpha/\beta$  boundary. It is possible that the lamellar  $\kappa_{III}$  and globular  $\kappa_{II}$  are essentially similar in chemical composition as they are being rejected at the same temperature from the same phase (Fig 7). Further evidence of the similarity of the  $\kappa_{II}$  and  $\kappa_{III}$  phases can be seen from the scanning electron micrograph (Fig 10) which illustrate  $\kappa_{II}$  and  $\kappa_{III}$  growing together. It is probable that the rosette  $\kappa_I$  phase can nucleate the  $\kappa_{III}$  around its perimeter, which may explain the dark etching band surrounding  $\kappa_I$  particles shown in as-cast microstructures. This is shown more clearly in Fig 11 where the continuity between the lamellar form of  $\kappa_{III}$  and the surrounding band is evident. At temperatures slightly below the  $\beta \rightarrow \alpha + \kappa_{II} + \kappa_{III}$  transformation, precipitates of  $\kappa_{IV}$  are noted within the grains (Fig 9). An electrolytically etched surface of an as-cast microstructure (Fig 12) shows clearly the lamellar structure of the  $\kappa_{III}$  phase.

13. The crystal structures of the phases described above are not well characterised. Recent electron diffraction studies of the  $\alpha$  phase by the authors have confirmed a face centred cubic structure with  $a = 3.57\text{\AA}$ . This compares favourably with  $\alpha$  in Cu - 10% Al of  $a = 3.62\text{\AA}$ . The crystal structure of the high temperature  $\beta$  phase cannot be confirmed by normal electron diffraction techniques as a complex martensitic structure is obtained on quenching from the  $\beta$  phase field. The normal high temperature  $\beta$  phase cannot exist at room temperature and

the, so-called, "retained  $\beta$ " should be described as  $\beta'$ . The structure of the martensite has been described as distorted hexagonal close packed<sup>(9)</sup> and recently as a mixture of face centred cubic and hexagonal close packed<sup>(10)</sup>.

14. Recent neutron diffraction<sup>(11)</sup> studies have confirmed that the rosette  $\kappa_I$  has a body centred cubic (b2) type of structure with a lattice parameter of 2.97Å. No crystal structure determinations of the lamellar and globular phases in nickel aluminium bronze have been reported.

#### HEAT TREATMENT OF NICKEL ALUMINIUM BRONZE

15. Heat treatment of the as-cast nickel aluminium bronze at temperatures under 840°C did not produce any changes in the major phases present except that retained  $\beta'$  was transformed to  $\alpha + \kappa$ . There was however a significant increase in the amount of fine precipitate present within the  $\alpha$  grains, shown in Fig 13. Closer examination of this precipitate in a sample heat treated at 675°C for 2 hours using SEM and extraction replication (Figs 14 and 15) has shown that the precipitates were a mixture of two distinct forms. One type, usually spheroidal (approximately 1  $\mu$ m in diameter) but on occasions closely resembling tiny  $\kappa_I$  rosettes, was iron rich, and was probably connected with the  $\kappa_{IV}$  precipitation within the  $\alpha$  grains found in as-cast materials. The second form (approximately 1  $\mu$ m x 0.1  $\mu$ m) designated by the authors as  $\kappa_V$  was cylindrical or lath shaped and was rich in nickel and aluminium. The exact analyses of these phases are discussed in a later section.

16. Increasing the heat treatment temperature to 740°C shown in Fig 16, and 790° shown in Fig 17, resulted in an increase in the size of the lath  $\kappa_V$  precipitates and the apparent disappearance of the globular  $\kappa_{IV}$  phase. This trend continued at 840°C (Fig 18), the  $\kappa_V$  phase having increased in size to a large rod-like form (approximately 10  $\mu$ m x 2  $\mu$ m). A similar trend was noticed when the alloys were held for longer times at lower temperatures. Figs 19 and 20 show the alloy heated at 675°C for 6 and 16 hours, and it was apparent that the lath phase had increased in size whereas the globular  $\kappa_{IV}$  phase was becoming less apparent and was not visible after the 16 hours treatment.

17. Above heat treatment temperatures of 820°C to 850°C the alloy can enter the  $\beta + \alpha + \kappa$  region depending on its exact composition. Heat treatment in this region for sufficient time resulted in spheroidisation of the  $\kappa$  phase and the resulting structure is shown in Fig 21.

18. There are various additional heat treatments that could be carried out on nickel aluminium bronze, in particular by quenching from elevated temperatures and tempering in an analogous manner to steel heat treatment. However these treatments are rarely applicable to large castings and have not been included in this paper.



## CHEMICAL ANALYSIS OF CONSTITUENT PHASES

### Experimental

#### Bulk Specimens

19. As cast specimens for phase analysis were held at 1000°C (i.e. in the  $\beta$  phase field) for 1h and then cooled at 8°C/min to intermediate temperatures before quenching in cold (20°C) water. The intermediate temperatures were 975°C reducing by 25°C intervals to 675°C.

20. Phase analysis was also carried out on heat treated specimens. The heat treatments employed were:

- a. 674°C - 2h, 6h and 16h air cooled;
- b. 740°C 3h air cooled;
- c. 790°C 3h air cooled;
- d. 840°C 3h air cooled;
- e. 860°C 72h air cooled.

21. Both as-cast and heat treated specimens were prepared for analysis by normal metallographic techniques. The specimens were examined on a Cambridge Scientific Instruments S600 SEM with a Link Systems Energy Dispersive Analysis attachment. Analyses were carried out with a spot size of 200 $\mu$ A and the data computed using the Nazir technique<sup>(12)</sup>.

22. Two stage carbon replicas were also taken from etched specimens and the extracted phases analysed in the STEM mode on a JEOL 100B electron microscope with an Energy Dispersive attachment.

#### Thin Foil Specimens

23. 3 mm diameter electron transmission thin foil specimens in the as-cast condition were prepared by ion beam machining and examined using a JEOL 100B/ electron microscope with a Link Systems Energy Dispersive Analysis attachment in the STEM mode. A spot size of about 200 $\mu$ A in diameter was used for analysis. The chemical composition of both bulk and thin foil specimens was as follows:

Al - 9.42%, Ni - 4.70%, Fe - 4.24%, Mn - 1.09%, copper remainder.

## ANALYSIS TECHNIQUES

#### Bulk Specimens

24. The quantitative analysis of bulk specimens by solid state Si(Li) X-ray detectors on scanning electron microscopes has developed rapidly over the last few years. The technique requires comparison of the characteristic X-ray peak intensity ( $I_x$ ) in the unknown sample with that of a well defined standard (e.g. pure X). Numerous computer programmes are available to evaluate the required atomic number (Z), absorption (A) and secondary fluorescence (F), corrections to the data obtained (ZAF). The accumulation of data from a multi-component alloy takes a considerable time and difficulty has been experienced

in maintaining instrumental parameters constant during analysis and this has been found to be a significant source of error.

25. To reduce the analysis time Nazir<sup>(12)</sup> has deduced analytical expressions and computed normalisation factors which compensate for atomic number corrections and X-ray transmission through the solid state detector. These factors allow concentrations to be calculated directly from the peak intensities of the alloy examined, without reference to standards.

26. In the analysis of nickel aluminium bronze the predominant correction is the absorption correction with respect to aluminium. To eliminate the necessity for computer correction, empirical absorption correction factors for aluminium in copper have been evaluated by analysing a series of Al-Cu alloys using ZAF correction programme and comparing the results with the data from the standardless technique of Nazir. The difference in the two sets of results represents, to a first approximation, the degree of absorption correction for aluminium in copper. The fluorescence correction is minimal. This technique has shown itself to have an accuracy comparable with the ZAF correction computer programme with a significant decrease in analysis time<sup>(13)</sup>.

#### Thin Foils

27. The technique employed was essentially that of Cliff and Lorimer<sup>(14)</sup> whereby quantitative analysis was obtained from a thin foil specimen with the X-ray intensities of the two elements measured simultaneously (at a constant KV and independent of specimen thickness).

$$\text{Thus } \frac{C_1}{C_2} = \frac{k_1 I_1}{k_2 I_2} \quad \text{where } C_1, C_2 - \text{concentration of two elements in alloy (wt \%)}$$

$k_1, k_2$  - intensity correction factors for the two elements

$I_1, I_2$  - characteristic X-ray intensities for each element

28. The correction factors for the elements were evaluated by analysing standards of known chemical composition and the resulting factors are shown in Table 3 for analysis at 100 KV.

Table 3  
Calibration Factors (k) for JEOL 100B/STEM at 100 KV

ELEMENT	FACTOR (k)
Mg	2.858
Al	1.711
Si	1.000
Ca	1.106
Mn	1.118
Fe	1.196
Ni	1.410
Cu	1.548
Zn	1.655

## RESULTS

29. The average chemical analysis of the six phases usually found in as-cast nickel aluminium bronze, using SEM and STEM (both thin foil and replicas) are shown in Table 4.

30. In most cases between 20 and 30 analyses were taken of each phase present and the standard deviations of these results are also shown in Table 4. No standard deviations are quoted when the number of analyses taken were less than 10. It is apparent from the analysis results that the chemical composition of constituent phases in nickel aluminium bronze can vary quite appreciably from specimen to specimen and within the same specimen. This is particularly pronounced with the various  $\kappa$  phases, indicating that they can exist over a wide range of chemical composition. The globular  $\kappa_I$  and  $\kappa_{IV}$  phases have similar compositions rich in iron, and are thought to be  $Fe_3^*Al$  where  $Fe^*$  is iron plus minor additions of copper, nickel and manganese. The  $\kappa_{II}$  and  $\kappa_{III}$  also have a wide range of compositions, and there appears to be a significant difference in the nickel:iron ratio of these phases which is consistent for each analysis technique. In the case of  $\kappa_{II}$  the percentage of iron generally exceeds that of nickel by approximately 5-10% whereas in  $\kappa_{III}$  nickel exceeds iron by a similar amount. It is apparent therefore that there are statistically significant differences in the composition of  $\kappa_{II}$  and  $\kappa_{III}$  despite the fact that these phases are precipitated from the matrix at the same temperature.

31. Analyses were also carried out on the boundary layer surrounding the  $\kappa_I$  phase, typically shown in Fig 11, and the mean analysis of this layer was Al - 16%, Mn - 1.2%, Fe - 22%, Ni - 34%, Cu - 26%. This is consistent with a  $\kappa_{III}$  analysis indicating a deposition of lamellar  $\kappa$  on the rosette  $\kappa_I$  phase.

32. The composition of the retained  $\beta$  phase in specimens that had been quenched from decreasing temperatures from 975°C to 675°C is shown in Fig 22. Only the major elements iron, nickel and aluminium are displayed as it is clear from the previous work that manganese is distributed evenly throughout the material. It can be seen in Fig 22 that the composition of the  $\beta$  accurately reflects the changes caused by the transformation to  $\alpha$  and  $\kappa$  phases. Below 900°C the large iron rich  $\kappa_I$  rosettes are formed with a corresponding decrease in the iron content of the  $\beta$ . This results in a slight increase in the aluminium and nickel content of the  $\beta$  until 825°C where the  $\kappa_{II}$  and  $\kappa_{III}$  (ni Al - Fe Al) phases start to form, with a consequent decrease in aluminium, nickel and iron in the  $\beta$ .

33. A similar survey of the changes in composition from its formation around 900°C down to room temperature was carried out. Little change in  $\alpha$  composition was noted through the temperature range with the exception of iron content which was approximately 5% at 900°C and was reduced to 2.7% at room temperature. This is consistent with formation of an iron rich precipitate within the  $\alpha$  phase on cooling.

34. The analyses carried out on the fine precipitates within the  $\alpha$  grains following various heat treatments are shown in Table 5. These results confirm the microscopical evidence that the high iron  $\kappa_{IV}$  phase is not apparent



following heat treatments at temperatures greater than  $740^{\circ}\text{C}$  or at  $675^{\circ}\text{C}$  for 16 hours. The lath-like  $\kappa_{\text{V}}$  precipitate, found in increasing volume as the heat treatment temperature is raised contains a substantial amount of aluminium, nickel and iron. It is interesting that the proportion of iron found in the phase increases as the temperature of heat treatment is raised, indicating that the iron rich  $\kappa_{\text{IV}}$  phase is taken up by the  $\kappa_{\text{V}}$  phase. This high temperature  $\kappa_{\text{V}}$  has a composition similar to that of the annealed  $\kappa$  produced after heat treatment at  $860^{\circ}\text{C}$  for 72 hours. Thus it is possible that an equilibrium  $\kappa$  phase is produced locally in the  $\alpha$  grains under the influence of heat treatment. Equilibrium conditions are more likely to develop in this area than elsewhere due to very large surface area to volume of these particles and their extremely close proximity to each other as shown in Figs 14 and 19. Under these conditions diffusion should be enhanced even at moderate heat treatment temperatures.

#### REFERENCES

##### Reference

- 1 Culpan E A. AUWE unpublished memo.
- 2 Culpan E A and Rose G. To be published.
- 3 Cook M, Fentiman W P and Davies E. J. Inst. Met. 1951-52, 80, 419-29.
- 4 Crofts W L J, Townsend D W and Bates A P. British Foundryman 1964, 57, 89.
- 5 Macken P J and Smith A A. The Aluminium Bronzes, Copper Dev Assoc Publication No 31, 1966.
- 6 Bradley, J N. Unpublished work.
- 7 Weill-Couly P and Arnaud D. Fonderie, 1973, 28, 123.
- 8 Duma J A. Naval Engineers J 1975 Feb, 45.
- 9 Pearson W B. Handbook of Lattice Spacings and Structures of Metals and Alloys. International Series of Monographs on Metal Physics and Physical Metallurgy Vol 4. Pergamon 1964.
- 10 Regidor J J, Cristina M A and Sistiaga J M. Rev. Metal. Cenim 1974, 10, 3, 165-170.
- 11 Booth J G. Private communication.
- 12 Nazir M. J. of Microscopy, 1976, 108, Part 1, 79.
- 13 Rose G and Moth D A. AUWE unpublished memo.
- 14 Cliff G and Lorimer G W. Proc. Fifth Eur. Cong. Electron Microscopy Manchester. Institute of Physics, London, 1972.

Table 4

Chemical analysis of phases present in cast nickel aluminium bronze

Phase	SEM/Bulk					STEM/Thin Foil					STEM/Replica				
	Al	Mn	Fe	Ni	Cu	Al	Mn	Fe	Ni	Cu	Al	Mn	Fe	Ni	Cu
$\alpha$	8.3 $\pm$ 1.7	1.4 $\pm$ 0.1	2.7 $\pm$ 2	2.5 $\pm$ 1.4	85.4 $\pm$ 4	8 $\pm$ 2	0.8 $\pm$ 0.3	2.4 $\pm$ 1	3 $\pm$ 2	86 $\pm$ 4	-	-	-	-	-
$\beta$	8.7	1.0	1.6	3.5	85.2	-	-	-	-	-	-	-	-	-	-
$\kappa_I$	13 $\pm$ 5	2 $\pm$ 0.4	55 $\pm$ 7	15 $\pm$ 3	15 $\pm$ 5	-	-	-	-	-	-	-	-	-	-
$\kappa_{II}$	19 $\pm$ 3	2.2 $\pm$ 0.6	32 $\pm$ 3	27 $\pm$ 4	21 $\pm$ 5	18 $\pm$ 4	1.6 $\pm$ 0.3	34 $\pm$ 5	24 $\pm$ 5	23 $\pm$ 4	19 $\pm$ 5	1.3 $\pm$ 0.1	34 $\pm$ 5	30 $\pm$ 3	15 $\pm$ 5
$\kappa_{III}$	18 $\pm$ 6	2 $\pm$ 0.3	22 $\pm$ 0.7	32 $\pm$ 2	26 $\pm$ 4	22 $\pm$ 4	1.6 $\pm$ 0.4	22 $\pm$ 5	28 $\pm$ 5	26 $\pm$ 4	-	-	-	-	-
$\kappa_{IV}$	20 $\pm$ 3	1.5 $\pm$ 0.3	62 $\pm$ 4	4 $\pm$ 1	13 $\pm$ 1	9 $\pm$ 4	1.6 $\pm$ 0.4	60 $\pm$ 8	6 $\pm$ 4	23 $\pm$ 6	14 $\pm$ 2	1.1 $\pm$ 0.4	63 $\pm$ 6	14 $\pm$ 4	8 $\pm$ 3




Table 5


Chemical analysis of the fine precipitates within the  $\kappa$  phase of heat treated nickel aluminium bronze

Phase	SEM/Bulk					STEM/Replica				
	Al	Mn	Fe	Ni	Cu	Al	Mn	Fe	Ni	Cu
$\kappa_{IV}$ globular phase (675°C for 2h)						13 $\pm$ 3	1 $\pm$ 0.2	62 $\pm$ 6	16 $\pm$ 3	8 $\pm$ 3
$\kappa_V$ lath phase (675°C for 2h)						23 $\pm$ 2	1 $\pm$ 0.3	25 $\pm$ 3	39 $\pm$ 2	11 $\pm$ 1
$\kappa_{IV}$ globular phase (675°C for 6h)						14 $\pm$ 2	1 $\pm$ 0.5	63 $\pm$ 6	14 $\pm$ 5	8 $\pm$ 5
$\kappa_V$ lath phase (675°C for 6h)						27 $\pm$ 4	1.5 $\pm$ 0.3	27 $\pm$ 4	35 $\pm$ 3	10 $\pm$ 2
$\kappa_V$ lath phase (675°C for 16h)						20 $\pm$ 3	1.3 $\pm$ 0.3	34 $\pm$ 3	35 $\pm$ 2	10 $\pm$ 1
$\kappa_V$ lath phase 740°C	26	1.1	26	21	26	21 $\pm$ 2	1.8 $\pm$ 0.5	33 $\pm$ 3	35 $\pm$ 2	9 $\pm$ 2
$\kappa_V$ lath phase 790°C	23	1.2	33	21	22	18 $\pm$ 2	1.6 $\pm$ 0.3	40 $\pm$ 2	30 $\pm$ 1	10 $\pm$ 1
large lath phase 840°C	25	1.1	34	21	19	17 $\pm$ 3	1.7 $\pm$ 0.1	39 $\pm$ 5	32 $\pm$ 3	10 $\pm$ 1
spheroidised $\kappa$ phase (840°C for 3 days)	19	1.6	35	24	21	17 $\pm$ 2	1.6 $\pm$ 0.2	40 $\pm$ 3	31 $\pm$ 3	10 $\pm$ 1

FIG. 1.




Vertical Section of the  
Cu-Al-Ni-Fe system at  
5% Ni, 5% Fe.



Binary Cu-Al system.

FIG. 1

FIG. 2.



Schematic Representation of Phase Breakdown

FIG. 2.

FIG. 3




Fig 3

Microstructure of sand cast nickel aluminium bronze showing constituent phases. (x 800)






Fig 4 Alloy quenched from  $1000^{\circ}\text{C}$  showing as-solidified  $\beta$  grain size (x 100)



Fig 5 Alloy slowly cooled from  $1000^{\circ}\text{C}$  to  $900^{\circ}\text{C}$  and quenched, showing nucleation of  $\alpha$  phase.

(x 100)



Fig 6 Alloy slowly cooled from  $1000^{\circ}\text{C}$  to  $825^{\circ}\text{C}$  and quenched, showing nucleation of globular  $\kappa_I$  with  $\alpha$  and  $\beta$  phases.

(x 800)



Fig 7 Alloy slowly cooled from  $1000^{\circ}\text{C}$  to  $800^{\circ}\text{C}$  and quenched, showing formation of  $\kappa_{II}$  and  $\kappa_{III}$  at the  $\alpha/\beta$  interface.

(x 800)




Fig 8

Alloy slowly cooled from  $1000^{\circ}\text{C}$  to  $725^{\circ}\text{C}$  and quenched, showing fine  $\kappa_{IV}$  precipitation within the  $\alpha$  grains.

(x 800)



Fig 9

Alloy slowly cooled from  $1000^{\circ}\text{C}$  to  $675^{\circ}\text{C}$  and quenched, showing typical as-cast structure.

(x 800)




Fig 10 Alloy slowly cooled from 1000°C to 775°C and quenched, showing lamellar  $\kappa_{III}$  and globular  $\kappa_{II}$  phase forming together.

(x 3000)



Fig 11 Rosette  $\kappa_I$  surrounded by lamellar  $\kappa_{III}$  phase.

(x 10000)






Fig 12 Lamellar  $\kappa_{III}$  phase.

(x 10000)



Fig 13 Alloy heat treated at  $675^{\circ}\text{C}$  for 6 hours, air cooled.

(x 600)



Fig 14

Alloy heat treated at 675°C for 2 hours, showing fine lath and globular precipitates.

(x 10000)



Fig 15

Extraction replica of specimen shown in Figure 14.

(x 12500)



Fig 16 Alloy heat treated at 740°C for 3 hours.

(x 10000)



Fig 17 Alloy heat treated at 790°C for 3 hours.

(x 10000)




Fig 18 Alloy heat treated at 840°C for 3 hours.

(x 5000)



Fig 19 Alloy heat treated at 675°C for 6 hours showing lath and globular precipitates.

(x 10000)





Fig 20 Alloy heat treated at  $675^{\circ}\text{C}$  for 16 hours.

(x 10000)




Fig 21 Alloy heat treated at  $860^{\circ}\text{C}$  for 72 hours.

(x 800)

Fig. 21.




FIG.22 VARIATION OF  $\beta$  COMPOSITION  
WITH RESPECT TO TEMPERATURE

## DOCUMENT CONTROL SHEET

Overall security classification of sheet ..... UNCLASSIFIED/UNLIMITED .....

(As far as possible this sheet should contain only unclassified information. If it is necessary to enter classified information, the box concerned must be marked to indicate the classification eg (R),(C) or (S)).

1. DRIC Reference (if known)	2. Originator's Reference AUWE Tech Note 580/78 Acc No 46194	3. Agency Reference	4. Report Security Classification UNCLASSIFIED/ UNLIMITED
5. Originator's Code (if known) 012500	6. Originator (Corporate Author) Name and Location Admiralty Underwater Weapons Establishment Portland, Dorset, UK		
5a. Sponsoring Agency's Code (if known)	6a. Sponsoring Agency (Contract Authority) Name and Location		
7. Title Microstructural Characterisation of Cast Nickel Aluminium Bronze			
7a. Title in Foreign Language (in the case of translations)			
7b. Presented at (for conference papers). Title, place and date of conference			
8. Author 1. Surname, initials Culpan E A	9a. Author 2 Rose G	9b. Authors 3, 4...	10. Date. pp. ref. July 78 45 14
11. Contract Number	12. Period	13. Project	14. Other References
15. Distribution statement			
15. Descriptors (or keywords)			
Abstract The morphology and chemical analysis of the complex phases present in cast nickel aluminium bronze of nominal composition 10% aluminium, 5% nickel and 5% iron, have been investigated using optical microscopy, scanning electron microscopy and scanning transmission electron microscopy, coupled to an energy dispersive analysis system. The development of the structure of nickel aluminium bronze from liquid metal to the room temperature structure has been followed and also the modifications to the structure produced by heat treatment.			



Detachable Abstract Cards

These abstract cards are inserted in A.U.W.E. reports and notes for the convenience of librarians and others who need to maintain an information index

<p><u>UNCLASSIFIED/UNLIMITED</u></p> <p>AUWE Technical Note 580/78 July 1978 E A Culpan and G Rose</p> <p>Microstructural Characterisation of Cast Nickel Aluminium Bronze</p> <p>The morphology and chemical analysis of the complex phases present in cast nickel aluminium bronze of nominal composition 10% aluminium, 5% nickel and 5% iron, have been investigated using optical microscopy, scanning electron microscopy and scanning transverse analysis system. The development of the structure of nickel aluminium bronze from liquid metal to the room temperature structure has been followed and also the modifications to the structure produced by heat treatment.</p>	<p><u>UNCLASSIFIED/UNLIMITED</u></p> <p>AUWE Technical Note 580/78 July 1978 E A Culpan and G Rose</p> <p>Microstructural Characterisation of Cast Nickel Aluminium Bronze</p> <p>The morphology and chemical analysis of the complex phases present in cast nickel aluminium bronze of nominal composition 10% aluminium, 5% nickel and 5% iron, have been investigated using optical microscopy, scanning electron microscopy and scanning transverse analysis system. The development of the structure of nickel aluminium bronze from liquid metal to the room temperature structure has been followed and also the modifications to the structure produced by heat treatment.</p>
<p><u>UNCLASSIFIED/UNLIMITED</u></p> <p>AUWE Technical Note 580/78 July 1978 E A Culpan and G Rose</p> <p>Microstructural Characterisation of Cast Nickel Aluminium Bronze</p> <p>The morphology and chemical analysis of the complex phases present in cast nickel aluminium bronze of nominal composition 10% aluminium, 5% nickel and 5% iron, have been investigated using optical microscopy, scanning electron microscopy and scanning transverse analysis system. The development of the structure of nickel aluminium bronze from liquid metal to the room temperature structure has been followed and also the modifications to the structure produced by heat treatment.</p>	<p><u>UNCLASSIFIED/UNLIMITED</u></p> <p>AUWE Technical Note 580/78 July 1978 E A Culpan and G Rose</p> <p>Microstructural Characterisation of Cast Nickel Aluminium Bronze</p> <p>The morphology and chemical analysis of the complex phases present in cast nickel aluminium bronze of nominal composition 10% aluminium, 5% nickel and 5% iron, have been investigated using optical microscopy, scanning electron microscopy and scanning transverse analysis system. The development of the structure of nickel aluminium bronze from liquid metal to the room temperature structure has been followed and also the modifications to the structure produced by heat treatment.</p>